


1001818 ...19	1002264	230V ~50Hz	16A max.	60 x 8,5 x 4,7 cm	1,08 kg
1001820 ...21	1002265			120 x 8,5 x 4,7 cm	2,06 kg



- DE** BETRIEBSANLEITUNG TEIL A
Deckenrosette
- EN** INSTRUCTION MANUAL PART A
Ceiling canopy
- FR** MODE D'EMPLOI PARTIE A
Patère
- ES** MANUAL DE INSTRUCCIONES PARTE A
Base para techo
- IT** ISTRUZIONI PER L'USO PARTE A
Rosone a plafone
- NL** GEBRUIKSAANWIJZING DEEL A
Plafondrozet
- DA** DRIFTSVEJLEDNING PART A
Loftrossette
- PL** INSTRUKCJA OBSŁUGI CZĘŚĆ A
Rozeta sufitowa
- RU** ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ ЧАСТЬ А
Потолочное основание
- SV** BRUKSANVISNING DEL A
Takbox
- TR** KULLANMA KILAVUZU BÖLÜM A
Tavan motifi
- HU** HASZNÁLATI UTASÍTÁS, A. RÉSZ
Takaróelem

1001818 ...19 ...20 ...21
1002264 ...65

