

EN - The installation requires expert knowledge and may be carried out only by an approved electrician under consideration of local and national regulations!

Technical Details are subject to change.

SLV UK Unit E Chiltern Park Boscombe Road, Bedfordshire LU5 4LT

B ⁺SLV

Operating Manual PART B Outdoor Luminaire 1007933

Read manual carefully and keep for further use!

Use as directed

Safety class I (1) ⊕- Connection with protective conductor. Operate only on an even, stable and tilt-fixed surface. Do not strain mechanically or expose to strong dirt contamination. Minimum distance of light source to illuminated surface: 0,5 m. IP44: Protection against foreign objects > Ø 1,0mm - Protection against splashing water from all directions.

Lamp replacement

⚠ Disconnect luminaire from mains and let it cool down. Suitable light sources: GU10, 25W max.

Care / Storage

⚠ Disconnect product from mains and let it cool down. Clean external surfaces regularly with a slightly moistened (water) cloth. Do not clean with pressure washer. The following influences may have unwanted effects on the product: acidic surrounding, high salt content in the air, cleaning agents, fertilizer, thawing salt, chemicals. Store dry and clean.

Electrical connection

The installation requires expert knowledge and may be carried out only by an approved electrician under consideration of local and national regulations! see figure A - Plug Install a UK BS1363 style plug. Note the instructions of the manufacturer of the plug. When used outdoors connect to an IP rated socket only (e.g. MLA part OP9N). see figure B - Fixed installation. Provide power to the required point of installation (refer to BS7671 for correct cabling methods). Suitable IP rated junction boxes should be used where required. The power source connections should be local and accessible via a suitable IP rated enclosure. Note the instructions of the manufacturer of the IP rated junction box. Connect the luminaire to the mains supply ensuring the correct polarity is observed.

SLV



Placement

Consider IP type. It must be suitable for the place of operation. Place in a way that product poses no danger(e.g. stumbling). Note the distance to the illuminated surface.

Putting into service

Insert light source. Check and clean gasket after each opening to maintain IP degree. Tighten screws evenly and cross-wise. see figure A - Plug: Connect the mains plug with an outdoor plug socket.

A Check for secure standing and proper function!