





**EN** – The light source is only replaceable by a professional. The control gear is only replaceable by a professional.

Technical Details are subject to change.

SLV UK Unit E Chiltern Park Boscombe Road, Bedfordshire LU5 4LT



Coperating Manual PART B Floor Stand Luminaire 1007961 ...62 ...63

Read manual carefully and keep for further use!

▲ Safety advices for installation and operation. Disregard may lead to danger of life, burning or fire! Do not alter or modify the product. Do not fasten anything on the product. Do not cover the product. Take out of service when suspecting a defect or malfunction and contact your dealer or a qualified electrician. Take measures that children get not harmed by the product. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or a qualified electrician to avoid hazard. Do not stare into the active light source.

Additional safety advices = 🖄

## Use as directed

Safety class II (2) - Safety insulated - Connection without protective conductor. Operate only on an even, stable and tilt-fixed surface. Operate only in dry indoor area. Do not strain mechanically or expose to strong dirt contamination. Admissible ambient temperature(ta): -20°C ...+45°C.

#### Light Source

The light source of this luminaire may only be replaced by the manufacturer, an authorized service technician or a comparable qualified person. This product contains a light source of the energy efficiency class F. Reference control setting: 3000K

### Care / Storage

⚠ Disconnect product from mains and let it cool down. Clean external surfaces regularly with a slightly moistened (water) cloth. Store dry and clean.

#### Placement

Place in a way that product poses no danger(e.g. stumbling).

#### Putting into service

Connect mains plug with mains plug socket.

# <sup>+</sup>SLV

R



יקוע



Switching-on: Press push-button shortly when luminaire is switched off. Switching-off: Press push-button long. Selection of adjustments: Press push-button shortly when luminaire is switched on. Following adjustments are possible Light color change Selection of the lighting rings (top – bottom – both rings) Brightness change The luminaire has a storage function. The last settings are saved. Turn the push-button to change the individual setting. The light flashes when the minimum or maximum adjustment is reached.

A Check for secure standing and proper function!

AR