


EN





EN - The installation requires expert knowledge and may be carried out only by an approved electrician under consideration of local and national regulations!

Technical Details are subject to change.

SLV UK Unit E Chiltern Park Boscombe Road, Bedfordshire LU5 4LT



Operating Manual PART B Floor Stand Luminaire 1007973 ...74

Read manual carefully and keep for further use!

▲ Safety advices for installation and operation. Disregard may lead to danger of life, burning or fire!
Do not alter or modify the product.
Do not fasten anything on the product.
Do not cover the product.
Operate only with intact protection glass.
The supply cord may not be covered with soil.
If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or a qualified electrician to avoid hazard.
Take out of service when suspecting a defect or malfunction and contact your dealer or a qualified electrician.
Take measures that children get not harmed by the product.
Additional safety advices = ▲

Use as directed

Safety class I (1) - Connection with protective conductor. Operate only on an even, stable and tilt-fixed surface. Do not strain mechanically or expose to strong dirt contamination. IP44: Protection against foreign objects > Ø 1,0mm - Protection against splashing water from all directions.

Lamp replacement

Disconnect luminaire from mains and let it cool down.
 Suitable light sources: GX53, 9W max.
 Mind the correct placement of the gasket.
 Clean gasket when dirty.
 Tighten screws evenly and cross-wise.

Care / Storage

⚠ Disconnect product from mains and let it cool down. Clean external surfaces regularly with a slightly moistened (water) cloth. Do not clean with pressure washer. The following influences may have unwanted effects on the product: acidic surrounding, high salt content in the air, cleaning agents, fertilizer, thawing salt, chemicals. Store dry and clean.

B ⁺SLV



Electrical connection

The installation requires expert knowledge and may be carried out only by an approved electrician under consideration of local and national regulations! see figure A - Plug Install a UK BS1363 style plug. Note the instructions of the manufacturer of the plug. When used outdoors connect to an IP rated socket only (e.g. MLA part OP9N). see figure B - Fixed installation. Provide power to the required point of installation (refer to BS7671 for correct cabling methods). Suitable IP rated junction boxes should be used where required. The power source connections should be local and accessible via a suitable IP rated power. Note the instructions of the manufacturer of the IP rated junction box. Connect the luminaire to the mains supply ensuring the correct polarity is observed.

Placement

Consider IP type. It must be suitable for the place of operation. Place in a way that product poses no danger(e.g. stumbling).

Putting into service

Insert light source. see figure A - Plug: Connect the mains plug with an outdoor plug socket. Ground spike must be fixed in a way that lumaire may not tilt. Ground spike may not be used in permanently wet soil.

A Check for secure standing and proper function!



R